



Owner's Manual

RFN WARRIOR PRO

SX-E15 / E15 Plus



Dear RFN Customer

Thank you for your trust in the RFN brand. We will accompany you on your journey to explore endless possibilities, find unknown answers, and enjoy an exciting off-road life.

This manual explains the correct and safe use of the vehicle and basic inspection procedures. Please read the operating instructions carefully.

If you have any questions about the operation or maintenance of your vehicle, please contact an authorized dealer.

Even if you sell the vehicle, please always leave this manual to the next owner for maintenance and service records.

Although this manual contains most of the vehicle information, the manufacturer will continuously improve product design and quality, which may lead to differences between the manual and the vehicle. Product specifications are subject to change without notice. If you have any questions, please consult your dealer.

Manufacturing Information

Manufacturer: Zhejiang Apollo Sports Technology Co., Ltd.

Address: 12-14 Jinheng 2nd Road, Jinyanshan Industrial Zone, Quanxi Town, Wuyi County, Jinhua City, Zhejiang Province, China

Vehicle Serial Number:

Motor Code:

Controller Code:

Battery Code:

Note: The vehicle serial number (SN code) will be used when ordering spare parts from authorized dealers or in case of vehicle theft.

Table of Contents

Dear RFN Customer	
Manufacturing Information	
1 Safety Information	1
1.1 Safety Instructions	1
1.2 Risk Levels	1
1.3 Safe Operation	1
1.4 Safe Riding	1
1.5 Other Safety Precautions	3
2 Vehicle Overview	4
2.1 Left View	4
2.2 Top View	5
3 Serial Number Locations	6
4 Control Components	7
4.1 Front Brake Lever	7
4.2 Electronic Throttle	7
4.3 Rear Brake Lever	7
4.4 Power On/Off	7
4.5 Side Stand	8
5 Electrical Components	9
5.1 Instrument Cluster	9
5.2 Power Button	10
6 Operation	17
6.3 Front Suspension Damping Adjustment	20
6.4 Rear Suspension Preload/Damping Adjustment	21
7 Pre-Ride Inspection	24
8 Riding Instructions	26
8.1 Starting	26
8.1.2 Power Button	27
8.2 Emergency Power Cut-off Switch	27
8.3 Acceleration/Deceleration	27
8.4 Braking	28
8.5 Shutdown and Parking	28
8.6 APP Control	29
9 Settings and Maintenance	30
9.1 Tires	31
9.2 Brake System	32
9.2 Brake System	33
9.2.1 Brake Lever	33
9.2.2 Brake Pads	34
9.2.3 Brake Fluid	34
9.2.4 Brake Disc	36
9.2.5 Brake Hoses	36
9.3 Suspension System	37
9.3.1 Suspension System Inspection	37
9.3.2 Wheel Bearings	38
9.3.3 Steering Column Bearings	39
9.3.4 Rear Fork Bearings	40
9.4 Drive System	41
9.4.1 Chain	41
9.5 Electrical System	42

9.5.1 Motor	42
9.5.2 Battery	42
For detailed instructions on charging the battery, please refer to the "Dashboard and Operation" section.	43
9.5.3 Fuse	43
9.6 Vehicle Torque Specifications	44
10 Cleaning and Storage	45
10.1 Vehicle Cleaning	45
10.2 Vehicle Storage	46
10.3 Li-ion Battery Storage	47
11. Technical Specifications	48
12. Warranty and Guarantee	51
13. After-Sales Service and Warranty Coverage Table	52
13.1 Start Date & General Provisions	52
13.2 Coverage Table (materials/workmanship defects only)	52
13.3 Exclusions / Warranty Void	53
13.4 Customer Rights & Service Modality	53
13.5 Claim Procedure	53
13.6 Transfer	54
14. Maintenance Guide	55
14.1 Electrical System Diagram	56
14.2 Electric Motorcycle Troubleshooting	57
14.3 Fault Code Table – Error List and Recommended Actions	59
14.4 General Troubleshooting Table	60
15. Technical Specifications	61

1 Safety Information

1.1 Safety Instructions

Many safety instructions must be followed to operate this product safely. Please carefully read these instructions and the following details.

Safety instructions are highlighted in the text and referenced in the relevant paragraphs.

For your own safety, please read this user manual completely before operating the vehicle to ensure you have a comprehensive understanding of how to operate and control the vehicle.

1.2 Risk Levels

DANGER

Indicates special preventive measures that must be followed. This is an important warning instruction in this manual. Disregarding warnings may result in serious injury or death, and may also cause damage to the vehicle.

WARNING

Indicates special operational measures that must be followed. This is an instruction that needs to be followed. Disregarding caution tips may put personnel and vehicles at uncontrollable safety risks.

1.3 Safe Operation

Safety largely depends on riding technique. Only riders with a formal license who have received proper training can safely operate this vehicle. Otherwise, do not drive this vehicle to avoid injury.

WARNING

Driver requirements: Well-trained in driving and necessary technical guidance for off-road riding, wearing off-road protective equipment, prohibition of driving under the influence of alcohol/drugs.

Do not lend the vehicle to personnel who are not suitable for driving.

Maintain the vehicle according to the maintenance instructions in this owner's manual to ensure safety and extend the vehicle's service life. Have the vehicle repaired only by authorized dealers.

1.4 Safe Riding

⚠ WARNING

This vehicle is for use only on professionally constructed off-road grounds. Do not ride in areas such as public roads, streets, or unknown outdoor environments.

Check the vehicle condition and surrounding environment before starting to avoid accidents.

Correct posture is important for maintaining balance. Hold the handlebars with both hands, keep your upper body upright, and place your feet on the footrests. Do not ride when you feel unwell or have abnormal health conditions.

Off-Road Gear Required Before Riding:

Armor: Please wear riding armor with protective functions. Off-road armor is required when driving this type of vehicle to best prevent injuries.

Helmet: Your helmet is the most important part of your protective equipment. A tested helmet can prevent serious head injuries in case of accidents. A professional off-road helmet is required.

Goggles: Regular glasses and sunglasses cannot provide sufficient protection. Professional off-road goggles compatible with off-road helmets are required.

Off-Road Gloves: Professional off-road gloves with joint and knuckle protection are required to reduce hand injuries in case of accidents.

Boots: Professional sturdy high-top off-road boots are required to provide more protection to legs and feet and improve riding safety.

Clothing: Professional long-sleeved and long-pants off-road suits and armor are required to protect arms and legs for better protection.

Modifications

Modifying the vehicle or removing original parts without manufacturer approval may reduce safety and cause serious injury. Consequences are your responsibility.

Load Considerations

Adding accessories or increasing load will cause changes in weight distribution, affecting steering and balance, which can easily lead to accidents.

Standard Load: Max load < 120 kg (264.5 lb)

When loading within this limit, please remember the following:

- The center of gravity should be kept at a lower level as much as possible.
- Distribute weight as evenly as possible to maintain balance.
- The load must be securely connected.
- Do not hang heavy or bulky items on the handlebars or suspension, which may cause imbalance and slow steering response.

NOTE!

The manufacturer only provides original accessories for your vehicle. Please contact an authorized dealer for this purpose.

The manufacturer disclaims all responsibility for third-party accessories; this responsibility is entirely yours.

When installing accessories, please remember the following:

- Do not install any accessories or transport any load that obstructs or limits ground clearance, suspension travel, steering, lighting, indicators, or reflectors.
- Accessories on the handlebars or front wheel suspension will damage steering performance, ensure that installed accessories are as light as possible.
- Do not install any luggage racks that may affect the vehicle's stability when facing headwinds.
- Have electrical accessories installed only by authorized dealers to correctly match the electrical system; improper installation may lead to loss of lighting, reduced motor power, and damage to the vehicle's electrical components.

1.5 Other Safety Precautions


Drive slowly and brake carefully on wet roads or slippery surfaces.

Safety Stickers




2 Vehicle Overview

2.1 Left View







1. Charging Port
2. Battery Lock
3. Frame
4. Rear Fender
5. Rear Shock Absorber
6. Front Wheel
7. Front Brake
8. Front Fork
9. Motor Controller
10. Lithium Battery Pack
11. Side Stand
12. Rear Swing Arm
13. Rear Brake
14. Rear Wheel
15. Front Fender

2.2 Top View


- 16. Handlebar
- 17. Rear Brake Lever
- 18. Dashboard / Instrument Panel
- 19. Front Brake Lever
- 20. Throttle Grip
- 21. Main Key Switch
- 22. Seat

3 Serial Number Locations

**3.1 Frame Number****3.2 Vehicle Nameplate****3.3 Motor Number****3.4 Battery Number**


4 Control Components

4.1 Front Brake Lever




Front brake lever ① is located on the right-hand side of the handlebar.

4.2 Electronic Throttle




Electronic throttle grip ① is located on the right-hand side of the handlebar.

4.3 Rear Brake Lever



Rear brake lever ① is located on the left-hand side of the handlebar.

4.4 Power On/Off




Power switch ① is located in front of the connector on the right side of the battery.

CAUTION

Switch off the main power immediately after finishing the ride to prevent unintended activation by others.

If the motorcycle remains parked with the display shut down and the main power switch is not turned off for an extended period, the system will automatically cut the power.

4.5 Side Stand



Side-stand bracket ① is mounted on the lower left side of the motorcycle.


5 Electrical Components

5.1 Instrument Cluster

Power On/Off (Method 1 — Ignition Key Switch):

Turn the key to the “” position. The instrument panel will light up — power is ON.


Turn the key to the “” position. All electrical systems will shut down — power is OFF.



Steering Lock:

Turn the handlebar fully to the left, then push the key downward and rotate it to the “” position to engage the steering lock.

Power On/Off (Method 2 — Push Button Start):



Press the button once to sink it. The instrument panel will light up — power is ON.

Press the button again to release it. All electrical systems will shut down — power is OFF.

Battery Lock Operation:

Unlocking the Battery Lock:

Turn the key fully to the left. The battery lock will pop up automatically.

Locking the Battery Lock:

Press the battery lock down until it clicks into place.

CAUTION

The same key is used for both the ignition and the battery lock.

5.2 Power Button

Button “P” Function:

Unlock P Mode

After powering on, the vehicle enters “P” (Park) mode by default.


Press and hold this button for 3 seconds to unlock.

After unlocking, the “READY” indicator on the display will remain ON.

Enter P Mode (Lock)

When the vehicle is in unlocked (driveable) mode, press and hold this button again for 3 seconds to return to “P” mode.

After entering P mode, the “READY” indicator on the display will turn OFF.



CAUTION

After each unlocking, the default mode is “Track” and the default gear is “LEVEL 1”.



Button “+” Function:

Shift Up (Up to 5 gears, equivalent to 5-speed petrol vehicles)

Press this button briefly to shift up one gear.

The current gear level will be displayed on the instrument as “LEVEL X”.

Change Throttle Output Curve

When the vehicle is powered on, press and hold this button for 3 seconds.

The throttle output curve will be switched.

Upon success, only decorative bars and code “00” will be shown on the display.

CAUTION

After each unlocking, the default gear is “LEVEL 1”.

Button “-” Function:

Shift Down (Up to 5 gears, equivalent to 5-speed petrol vehicles)

Press this button briefly to shift down one gear.

The current gear level will be shown on the instrument as “LEVEL X”.

⚠ CAUTION

After each unlocking, the default gear is “LEVEL 1”.

Gear Level Characteristics:

Gear Level	Output Power	Max Speed
Level 1	3 kW	50 km/h (31 mph)
Level 2	6 kW	65 km/h (40 mph)
Level 3	9 kW	80 km/h (50 mph)
Level 4	12 kW	90 km/h (56 mph)
Level 5	15 kW	90 km/h (56 mph)
		
Function	Status	Logic & Actual Display
Full Display	After Power On	When the ignition is turned on (power supplied), all icons light up for 2s.
Communication Fault	No communication established	First turn off all icons; Speed frame __, numeric display --, flashes (1Hz).
Button Operation (Bottom Switch)	Long press (>2s)	Speed unit __, mileage unit __ switch simultaneously, settings saved after power off.
	Short press	Display type switch: mileage count, time count.
Power System Fault Indicator	Off	No alarm.
	On	Communication received fault codes related to motor, battery, or controller.
Battery Status Indicator	Off	No alarm.
	On	Battery charge lower than 20%.
	Flashing	1. Communication received battery-related fault codes; 2. During charging state.
Riding Status Indicator: P Gear	Off	P gear locked.
	On	Unlocked, enter rideable state.
Gear Indicator	Off frame + number	When entering fault code display state.
	On P	Not in rideable state.
	On 0	Enter power limit gear.
	On 1	Forward gear 1.
	On 2	Forward gear 2.

Gear Level	Output Power	Max Speed
	On 3	Forward gear 3.
	On 4	Forward gear 4.
	On 5	Forward gear 5.
	On R	Reverse gear.
Riding Mode: Sport	Off	1. In fault code display state; 2. Not in this riding mode.
	On	In this riding mode.
Riding Mode: Track	Off	1. In fault code display state; 2. Not in this riding mode.
	On	In this riding mode.
Battery Display	On	1. Battery SOC shown as dynamic percentage; 2. SOC value converted to battery icon display, bars turn off right to left, each bar = 10% capacity.
Speed Display	Only unit displayed	When speed < 1.
	On	Three-digit numeric display + unit letter; Default km/h, not showing tens/hundreds if speed too low, max 199, beyond shows 199; Formula: Motor $RPM \times 60 / 3.42 \times 11 / 48 \times 1890 / 1000000$.
Motor Temp	On	Motor symbol + three-digit numeric display + unit; Not showing tens/hundreds if too low, max 199, beyond shows 199.
	Flashing (1Hz)	1. When exceeding motor temp limit, motor symbol flashes; 2. Below 0°C, numbers flash.
Battery Temp	On	Battery symbol + three-digit numeric display + unit; Not showing tens/hundreds if too low, max 199, beyond shows 199.
	Flashing (1Hz)	1. When exceeding battery temp limit, battery symbol flashes; 2. Below 0°C, numbers flash.
Controller Temp	On	Controller symbol + three-digit numeric display + unit; Not showing tens/hundreds if too low, max 199, beyond shows 199.
	Flashing (1Hz)	1. When exceeding controller temp limit, controller symbol flashes; 2. Below 0°C, numbers flash.

5.3 Dashboard

Error Code List

Code	Fault Description
01	Bus Overvoltage
02	Bus Undervoltage
03	Phase Current Overcurrent

Code	Fault Description
04	Controller Overload
05	U Phase Loss
06	V Phase Loss
07	W Phase Loss
08	Phase-to-Phase Short Circuit / Motor Fault
09	MOSFET High-Side Fault
10	MOSFET Low-Side Fault
11	MOSFET U-Side Fault
12	MOSFET V-Side Fault
13	MOSFET W-Side Fault
14	Phase Current Zero Offset Fault
15	Bus Current Zero Offset Fault
16	Motor Locked Rotor
17	Motor Overtemperature
18	Motor Overspeed
19	Controller Overtemperature
20	Motor Thermal Sensor Open Circuit
21	Motor Thermal Sensor Short Circuit
22	Motor Hall Sensor Fault
23	Throttle Fault: Not Returning or Disconnected
24	Anti-theft Alarm Triggered
25	Gear Switch Fault: Not Connected or Damaged (CAN ID116, BYTE4 Bit0)
26–56	Reserved Controller Fault Codes
57	Battery Cell Overvoltage
58	Battery Cell Undervoltage / SOC Too Low
59	Battery Cell Voltage Loss (Disconnected)
60	Excessive Voltage Deviation Between Cells
61	Battery Cell Failure
62	Charger Overvoltage
63	Charger Undervoltage
64	Reserved
65	Discharge Overcurrent
66	Charge Overcurrent
67	Regenerative Overcurrent
68	Cell Current Signal Lost
69	Discharge Hardware Overcurrent Protection
70	Discharge MOSFET Failure
71	Charge MOSFET Failure
72	Fuse Blown
73	Battery Overtemperature
74	Battery Undertemperature
75	BMS Overtemperature
76	BMS Undertemperature
77	MOSFET Overtemperature Protection
78	Battery Cell Temperature Lost
79	BMS Temperature Signal Lost

Code	Fault Description
80	BMS Balancing Circuit Failure (CAN ID206, BYTE4 Bit7)
81	Battery Internal Resistance Too High
82	Single Cell Internal Resistance Too High
83	Battery Pack Over-discharge Protection
84	Single Cell Over-discharge Protection
85	Excessive Battery Humidity
86	Insulation Resistance Too Low
87	Battery Water Ingress Protection Triggered
88	Reserved
89	VCU Communication Lost
90	Charger Communication Lost
91–104	Reserved Battery BMS Fault Codes
105	Charger Input Undervoltage Protection
106	Charger Input Overvoltage Protection
107	Charger Output Undervoltage Protection
108	Charger Output Overvoltage Protection
109	Charger Overtemperature Protection
110	Charger Overcurrent Protection
111	Charger Short Circuit Protection
112	Charger Reverse Polarity Protection
113	Charger No-load Protection
114	Charger Inverter Overload Protection
115	Charger Inverter Overvoltage Protection
116	Charger Inverter Undervoltage Protection
117–120	Reserved Charger Fault Codes
121–199	Reserved for Other Equipment Faults

5.4 Electrical Components

1. Battery Charger

The vehicle is equipped with a battery charger. When the power level on the instrument panel drops below 20%, the "L" bar will flash as a reminder. Please charge the vehicle immediately.

Only use the original charger provided by the manufacturer.

Two charging modes are available (indicated by LED status). Press and hold the button on the charger for 2 seconds to switch between 10A and 5A charging rates.

2. Charging Port

The battery can be charged while installed on the vehicle or when removed.

When not charging, it is recommended to cover the charging port with the dust cap to prevent foreign objects from entering, which may lead to damage or corrosion of the charging connector and pose safety risks.

Note!

The indicator light on the charger provides both charging status and fault information.

The charging port (1) is located on the battery pack.

Always keep the dust cap on the charging port when not in use.

The battery (1) is located beneath the battery cover.

3. Battery

Always observe the warnings labeled on the battery.

Charging temperature range: 0°C to 45°C (32°F to 113°F)

Discharging temperature range: -15°C to 55°C (5°F to 131°F)

If the battery's remaining charge is very low, charge it fully before long-term storage.

If not used for an extended period, it is recommended to recharge the battery at least once every 30 days.

If left unused for more than 90 days, the battery may enter sleep mode due to low voltage.

To reactivate the battery from sleep mode:

First, connect the charger to the battery, and then plug the charger into an AC power outlet.

 WARNING!

Do not disassemble or physically damage the battery.

Do not expose the battery to environments outside the operating temperature range of -15°C to 55°C (5°F to 131°F).

Do not immerse a battery—especially one with unsealed or disconnected ports—in water, acid, alkaline solution, or saltwater.

Always read and follow the warning labels on the battery before use.

 WARNING!

If the battery charge level drops below 20%, the system will automatically limit output power and enter protective mode.

If the charge level falls below 10%, recharge the battery immediately!

Failure to do so may result in irreversible damage to the battery.


 CAUTION

Regularly recharge the battery to avoid complete discharge.

Do not allow the battery to be fully depleted over extended periods.

6 Operation

6.1 Onboard Charging Procedure



Power off the vehicle completely.

Insert the charging plug into the charging port located on the left side of the vehicle (mounted on the body).

Connect the other end of the charger to the battery socket.

Plug the charger's power cord into a 220V AC wall outlet.

Once charging begins, the charger indicator lights will show charging status.

When charging is complete, the indicator lights will remain solid and charging noise will decrease.

Unplug and cover the charging port to complete the procedure.

⚠ WARNING!

Never allow the battery to be fully depleted.

Doing so can cause permanent damage to the battery.

Batteries damaged by deep discharge due to improper handling cannot be repaired and must be replaced at the owner's expense.

⚠ CAUTION

Charge the battery regularly—avoid letting it fully discharge.


Do not turn on the vehicle while the battery is charging.

Ensure the protective charging port cover is closed after charging is completed.


6.2 Battery Removal & Installation

To Remove the Battery:


Open the seat.




Unlock the battery latch mechanism.



Disconnect the main vehicle connector.



Unplug the power connector.



Lift the battery upward to remove it.

To Install the Battery:

Insert the battery by following the above steps in reverse order.

⚠ WARNING!

Do not disassemble the battery under any circumstances.


Do not drop, strike, or apply force to the battery.

⚠ CAUTION

Always perform this procedure with the vehicle powered off..

6.3 Front Suspension Damping Adjustment

1. Ensure the motorcycle is powered off.
2. Park the vehicle securely using the parking stand.
3. Use the appropriate tool to adjust the upper and lower damping knobs on the fork.



Note!

The upper adjustment knob (①) on the front fork controls rebound damping.

Turning the knob clockwise (+) slows down the rebound.

Turning the knob counterclockwise (–) speeds up the rebound.

The lower adjustment knob (②) on the front fork controls compression damping.

Turning the knob clockwise (+) increases compression damping, making the suspension stiffer.

⚠ WARNING!

Do not disassemble the suspension components. Doing so may result in serious injury.

If damping adjustment becomes ineffective, contact your authorised dealer immediately.

⚠ CAUTION

Avoid setting the rebound or compression damping adjusters to their extreme limits.

If maximum or minimum adjustment is required, it is recommended to turn back one click to prevent damage to the suspension

6.4 Rear Suspension Preload/Damping Adjustment

1. Ensure the motorcycle is powered off.
2. Park the vehicle securely using the parking stand.

Preload Adjustment:

Loosen the lock ring (①) at the top of the shock absorber spring.

- Turn counterclockwise to loosen
- Turn clockwise to tighten

The upper adjustment knob (①) controls compression damping.

The lower adjustment knob (②) controls rebound damping.

Compression Damping (①):



Turn clockwise (+): Suspension becomes stiffer (harder compression).

Turn counterclockwise (-): Suspension becomes softer (easier compression).

Rebound Damping (②):

Turn clockwise (+): Rebound becomes slower.

Turn counterclockwise (-): Rebound becomes faster.



WARNING!

Do not disassemble the suspension components. Doing so may result in serious injury.

If damping adjustment becomes ineffective, contact your authorised dealer immediately.

CAUTION


Avoid setting the rebound or compression damping adjusters to their extreme limits.

If maximum or minimum adjustment is required, it is recommended to turn back one click to prevent damage to the suspension

6.5 Steering Lock Activation

To Lock the Handlebar:


1. Ensure the vehicle is powered off.
2. Turn the handlebar fully to the left.
3. Insert the key and turn it to the left to engage the steering lock mechanism.
4. Confirm the steering is locked securely..



6.6 Parking the Vehicle

To Park the Vehicle:

1. Ensure the vehicle is powered off.
2. Stabilize the vehicle.
3. Deploy the side stand to support the bike.
4. Parking procedure is complete.



7 Pre-Ride Inspection

WARNING!

Do not ride the motorcycle if any component is found to be defective.

The manufacturer provides no warranty coverage for damage or safety incidents caused by:

- Negligence on the part of the authorised dealer
- Improper vehicle care and maintenance by the user
- Operation that violates the guidelines of this manual

CAUTION

For your own safety, always perform a pre-ride inspection before each use.

This helps prevent accidents resulting from unexpected mechanical failures.

Pre-departure Inspection Table:

Checkpoint	Verification
Brake System	Perform inspection while stationary. When you pull the brake, it must not be pulled all the way to the handlebar. The brake system must have stable pressure point when working. If you need to pull the brake lever several times to achieve the desired braking force, contact an authorized dealer to check the brake system. Check brake lines, no fluid leakage. Check brake pads. If brake pads are worn to only 1mm at any point, replace both brake pads.
Wheels	Check if wheels operate normally. Check tires for damage and tread wear. Check tire pressure, correct if necessary.
Throttle	Check if throttle functions normally, rotates smoothly without sticking. Check if it returns to position normally.
Side Stand	Check operating status. If the vehicle is turned on and the throttle lever is rotated, the side stand should not cut power when folded.
Vehicle Body and Suspension	Check that bolts, nuts, and screws are tight.
Chassis	Check the function of shock absorbers by compressing them several times. Also check front and rear shock absorbers for leaks and dirt. Apply front brake, push down on handlebars several times to check if front suspension works properly. Push down on seat several times to check if rear shock absorbers work properly.
Instrument and Lighting	Check if the instrument panel and all lights on the vehicle work properly. This is especially important to be noticed by other traffic participants.

Checkpoint	Verification
Li-ion Battery	Before use, make sure the battery is always fully charged.
Steering	Check for trouble-free operation, lubricate steering pivot if necessary.

⚠ WARNING!

Before riding, make sure you are fully familiar with all control components and their functions.

If you have any questions or uncertainties, contact your authorised dealer immediately.


8 Riding Instructions

8.1 Starting

8.1.1 Power On/Off (Method 1 — Ignition Key Switch):

Turn the key to the “” position. The instrument panel will light up — power is ON.


Turn the key to the “” position. All electrical systems will shut down — power is OFF.



Steering Lock:

Turn the handlebar fully to the left, then push the key downward and rotate it to the “” position to engage the steering lock.

Power On/Off (Method 2 — Push Button Start):



Press the button once to sink it. The instrument panel will light up — power is ON.

Press the button again to release it. All electrical systems will shut down — power is OFF.

Battery Lock Operation:

Unlocking the Battery Lock:

Turn the key fully to the left. The battery lock will pop up automatically.

Locking the Battery Lock:

Press the battery lock down until it clicks into place.

CAUTION

The same key is used for both the ignition and the battery lock.

8.1.2 Power Button

Button “P” Function:

Unlock P Mode

After powering on, the vehicle enters “P” (Park) mode by default.


Press and hold this button for 3 seconds to unlock.

After unlocking, the “READY” indicator on the display will remain ON.

Enter P Mode (Lock)

When the vehicle is in unlocked (driveable) mode, press and hold this button again for 3 seconds to return to “P” mode.

After entering P mode, the “READY” indicator on the display will turn OFF.




CAUTION

After each unlocking, the default gear is “LEVEL 1”.


8.2 Emergency Power Cut-off Switch

The emergency power cut-off switch is designed to immediately disconnect the main power supply of the vehicle in case of abnormal conditions or dangerous situations. Activating this switch will instantly stop the motor output, preventing unintended acceleration.




8.3 Acceleration/Deceleration

1. Rotate the throttle grip in direction (a) to accelerate the motorcycle.
2. Rotate the throttle grip in direction (b) to decelerate the motorcycle.



8.4 Braking

1. Fully release the throttle grip (b) to initiate deceleration.
2. Simultaneously apply both the front and rear brakes, gradually increasing braking force (c).



WARNING!

Avoid sudden or aggressive braking, as this may cause the tyres to lose traction and skid.


On wet or slippery surfaces, braking distances will be significantly increased.

Avoid riding in extreme weather conditions such as heavy rain whenever possible.

When riding downhill on dry roads, apply the brakes gently and continuously to maintain control and prevent brake overheating.

8.5 Shutdown and Parking

- Turn the key to the “’ position. All electrical systems will shut down — power is OFF/Or: Press the button again to release it. All electrical systems will shut down — power is OFF.
- Dismount and use the side stand to park the vehicle securely.

**⚠ CAUTION**

Ensure the vehicle is parked on a stable and level surface.

8.6 APP Control

For detailed operation instructions, please scan the QR code provided.



9 Settings and Maintenance

The safety and condition of the motorcycle depend on proper maintenance, regular inspections, adjustments, and lubrication.

On the following pages, you will find relevant instructions.

These maintenance guidelines will assist you in performing preventive care and basic servicing.

However, some maintenance tasks require specialised tools.

WARNING!

Do not attempt any maintenance work that you are unfamiliar with or that may affect warranty coverage.

Unauthorised modifications to the motorcycle may alter its performance and compromise safe operation.

Any such modifications performed without manufacturer approval will void the warranty.

When checking tyre pressure, ensure that the tyres are at ambient temperature.

Always inspect tyre pressure before every ride to ensure it is within the recommended range.


CAUTION

All maintenance work should be performed by an authorised and qualified dealer.

9.1 Tires

For best tire performance, durability, and safe operation, please refer to the following tire instructions.

Tire Inspection



SX-E15 / SX-E15 PLUS

Front Tyre and Rim Size

Rim: 19 × 1.6 / 21 × 1.6

Tyre: 70/100-19 / 80/100-21

Rear Tyre and Rim Size

Rim: 16 × 1.85 / 18 × 1.85

Tyre: 90/100-16 / 100/90-18

Tyre Tread Depth Inspection ①

The recommended minimum tread depth is 3 mm.

If tread depth is below this value, replace the tyre immediately.

Tyre Sidewall Inspection ②

If cracks or visible damage appear on the tyre sidewall, replace the tyre immediately.

Tyre Wear Indicator Inspection ③

If the tread wears down to the wear indicator, the tyre is no longer safe for use and must be replaced promptly.

Tire	Tire Pressure
Front Tire	1 Bar (14.7 psi)
Rear Tire	1 Bar (14.7 psi)

WARNING!

Do not overload the motorcycle.

Excessive load increases pressure on the tyres during rotation and adds strain to the braking and steering systems.

This can lead to component failure or accidents.

Proper weight distribution on the motorcycle is critical for safe operation.

 WARNING!

Inspect tyre wear before every ride.

If the tread has reached the wear indicator, contact a qualified technician immediately to replace the tyre.

This is essential for your safety.

 WARNING!

Tyre wear directly affects riding stability.

Do not continue riding if the tyre is worn beyond the limit or visibly damaged.

Dealers are responsible for checking tyre condition at the time of sale and during maintenance.

 CAUTION

Tyre pressure must be checked before every ride and corrected as needed.

Check tyre pressure regularly.

 CAUTION

To ensure optimal performance, durability, and safe operation of the motorcycle, always follow the guidelines related to rims.

Before each ride, inspect the rims for cracks or deformation.

Damaged rims must be replaced by an authorised dealer.

Do not attempt to repair bent or broken rims yourself — they must be replaced.

 CAUTION

The technical values provided are for reference and may differ from legal requirements in your region. Always comply with local regulations.

9.2 Brake System

(For safe use of brakes, please refer to the following tire instructions.)

9.2 Brake System

For safety guidelines related to braking, refer to the tyre section above.

9.2.1 Brake Lever

Front Brake Lever ① (located on the right side of the handlebar):

Power off the motorcycle and park it on level ground or lift it securely using a stand.

Check that the lever moves smoothly. If there is any stiffness or sticking, apply lubricant to the pivot point ③.


Pull the brake lever and assess the brake feel. If it feels excessively soft, brake fluid or brake pads may need to be replaced.

Rear Brake Lever ② (located on the left side of the handlebar):

Power off the motorcycle and park it on level ground or lift it securely using a stand.

Check that the lever operates smoothly. If movement is stiff, apply lubricant to the pivot point ③.

Pull the brake lever and assess the braking force. If it feels too soft, brake fluid or brake pads should be replaced promptly.



⚠ WARNING!

If the brake lever feels soft or spongy and braking performance is reduced, this may be due to water or air entering the brake system, or damaged brake components.

This condition can severely reduce braking force and may lead to loss of control.

If such symptoms occur, stop riding immediately and contact an authorised dealer for inspection and repair.


⚠ CAUTION

Check both front and rear brake levers regularly to ensure they function properly.

The pivot points of both brake levers must be lubricated periodically to maintain effective braking force.

If you encounter any braking issues, contact an authorised dealer for a thorough inspection of the brake system.

9.2.2 Brake Pads



- (1) brake pads
- (2) front brake caliper
- (3) brake disc
- (4) brake pads
- (5) front brake caliper
- (6) brake disc

Front / Rear Brake Pad Inspection

Before every ride, inspect the front and rear brake pads as outlined in the maintenance schedule.

If the brake pad thickness has worn down to the wear limit indicator or is less than 0.5 mm (①), replace the entire set of brake pads immediately.


⚠ CAUTION

If you experience any braking issues, contact an authorised dealer to inspect the brake system.

9.2.3 Brake Fluid

Brake Fluid Inspection

(1) LOWER level mark



With the motorcycle in an upright position, check the fluid level.

It should be above the LOWER level mark (1). If the level is at or below the LOWER level mark, check the brake pads for wear .

Worn brake pads should be replaced. If the pads are not worn, have your brake system inspected for leaks.

If the front brake lever freeplay exceeds 0.8 in (20 mm), there is probably air in the brake system and it must be bled. See your motorcycle dealer for brake bleeding.


Adding Front Brake Fluid

When adding brake fluid be sure the reservoir is horizontal before the cap is removed or brake fluid may spill out.

(2) Screws

(3) reservoir cap

(4) diaphragm



1.Remove the screws (2), reservoir cap (3) and diaphragm (4).

2.Fill the reservoir with brake fluid. Do not overfill.

3.Reinstall the diaphragm and reservoir cap.

4. Tighten the screws to the specified torque: 0.7 lbf·ft (1.0 N·m, 0.1 kgf·m).

⚠ CAUTION

If you experience any braking issues, contact an authorised dealer to inspect the brake system.

9.2.4 Brake Disc

Before every ride, inspect the brake disc for signs of warping or unusual wear marks on the disc surface.

If any deformation or abnormal friction patterns are found, do not ride and have the brake disc inspected by an authorised dealer.

⚠ CAUTION

If you experience any braking issues, contact an authorised dealer to inspect the brake system.

9.2.5 Brake Hoses

Before every ride, inspect the brake hoses (①, ②) for signs of bending, ageing, or abnormal abrasion.

If any damage or wear is found, contact an authorised dealer to replace the hoses.

⚠ WARNING!

Do not attempt to disassemble the brake hoses yourself — brake fluid is corrosive and may cause injury.

Do not modify the routing of the brake hoses, as this may lead to abnormal pressure points and brake failure.

⚠ CAUTION

Ensure the brake hoses do not interfere with any part of the vehicle during operation.

If you experience any braking issues, contact an authorised dealer for a complete brake system inspection.

9.3 Suspension System

Before each ride, a brief inspection of suspension components must be carried out, and repairs should be made if necessary.


9.3.1 Suspension System Inspection

Front Fork Inspection

Park the motorcycle upright on level ground.

Check the fork tube surfaces for scratches, damage, or oil leakage.

Hold the front brake lever and press down on the handlebars several times to verify that the front suspension compresses and rebounds smoothly.



Rear Shock Absorber Inspection:

Inspect the shock shaft and housing for scratches, damage, or oil leakage.

Press down firmly on the seat multiple times to ensure the rear suspension is operating correctly.

⚠ WARNING!

Before riding, check that the front suspension and fork guards do not interfere with the tyres or brake system.

Also inspect for oil leakage.

Any interference or leakage may lead to a serious safety hazard.


If such issues are found, stop riding and contact an authorised dealer immediately.

⚠ CAUTION


The suspension must operate smoothly without any shaking or vibration.

If abnormal behaviour is observed, have the vehicle inspected by an authorised dealer. Perform regular maintenance and minor repairs as recommended.

9.3.2 Wheel Bearings



Check the play in the bearing



Wheel Bearing Inspection

Place the motorcycle on a lift stand and remove the wheel.

Use a suitable tool to move the wheel bearing side-to-side and assess any play or looseness.

⚠ CAUTION


Before every ride, perform a brief check of the steering components and service them if necessary.

Wheel bearings must be inspected in accordance with the maintenance schedule.

If you notice excessive play in the hub or difficulty in wheel rotation, contact your authorised dealer for further inspection.

9.3.3 Steering Column Bearings

Shake the handlebars



Steering Head Bearing Inspection

Place the motorcycle on a lift stand.

Gently move the front end side to side to check for any noticeable play in the steering head bearings.

⚠ WARNING!

Regularly inspect the condition of the steering head bearings.

Worn or loose bearings can lead to hazardous riding conditions.

Always lubricate and service the steering bearings as part of scheduled maintenance, and replace them if necessary.

CAUTION

Before every ride, perform a brief check of the steering components and arrange for servicing if needed.

If any looseness or abnormality is detected, have the motorcycle inspected by an authorised dealer.

9.3.4 Rear Fork Bearings

Rear Swingarm Bearing Inspection

Place the motorcycle on a lift stand and remove the rear wheel.

Detach the rear shock absorber, then gently move the swingarm side to side to check for any noticeable play in the bearings.

WARNING!

Regularly inspect the condition of the rear swingarm bearings.

Excessive wear or looseness may pose a safety risk.

Ensure that the bearings are properly lubricated and serviced as needed, and replace them if any abnormalities are found.

CAUTION

Before every ride, briefly inspect the swingarm assembly.

If any irregularities are detected, have the component serviced or inspected by an authorised dealer.

9.4 Drive System

9.4.1 Chain

Drive Chain Adjustment

Place the motorcycle on a lift stand.

Loosen the rear axle nut (①).

Loosen the chain adjuster lock nuts (②).

With the motorcycle unloaded, turn the adjustment bolts (③) until the chain slack is between 20–25 mm.

Tighten the rear axle nut to a torque of 55–60 N·m.

CAUTION

The rear axle nut must be torqued using a certified torque wrench to avoid damage to the vehicle.

Incorrect chain slack may lead to premature wear or damage to the sprockets, bearings, chainwheel, or the chain itself.

In the worst case, the chain could break or derail, which may result in a traffic accident.

If the chain is rusty, kinked, or has excessive lateral movement, it must be replaced immediately.

9.5 Electrical System

9.5.1 Motor

Motor Inspection

Place the motorcycle on a stand so that the rear wheel is lifted off the ground.

Remove the drive chain and inspect the front sprocket for signs of wear.

Power on the motorcycle and gently rotate the throttle grip to observe the motor (①).

Check for abnormal noise or resistance during rotation.

CAUTION


If the motor exhibits abnormal noise or any signs of binding, contact your authorised dealer immediately.

Keep hands, tools, and loose items away from rotating components during operation.

Do not touch the sprocket or motor while it is in motion.

9.5.2 Battery

The vehicle is equipped with a maintenance-free battery.



WARNING!

Never attempt to open the battery. Doing so is dangerous and will cause permanent and severe damage to the battery.

CAUTION

Keep the battery away from open flames, cigarettes, or any other hazardous environments, and always ensure adequate ventilation.

When charging the battery indoors, make sure it is always placed in a safe location.

For detailed instructions on charging the battery, please refer to the "Dashboard and Operation" section.

9.5.3 Fuse

If the dashboard, headlight (if equipped), or other systems do not function after turning on the main switch or ignition, the issue may be caused by a blown fuse.

Before Replacing the Fuse:

Turn off the main switch or ignition key.

Disconnect the battery connector and remove the battery from the vehicle.

Fuse Inspection:

Open the white plastic fuse holder located on the main wiring harness in front of the battery.

Inside the holder, there is a spare 10A glass tube fuse.

Check the spare fuse for:

No visible damage

No broken or melted metal filament inside

To Replace the Fuse:

Remove the blown fuse from the holder.

Insert the spare fuse into the slot.

Do not touch the glass section of the fuse during insertion.

WARNING!

If the new fuse blows again immediately after powering on, contact your dealer to inspect the system for underlying electrical issues.

For any repairs, contact an authorized dealer. They have the special tools, expertise, and experience to perform repairs correctly.

Always use genuine OEM parts. Counterfeit or non-original parts may appear similar but can cause incompatibility or further damage.

9.6 Vehicle Torque Specifications

Component Location	Bolt Specification	Grade	Tightening Torque (Nm)
Front Wheel Axle	M16	10.9	30–35 Nm
Expansion Bolt	M14	10.9	40–45 Nm
Front Shock Absorber Bottom Bolt	M6	8.8	9–12 Nm
Front/Rear Brake Disc Bolt	M8	10.9	20–25 Nm
Upper/Lower Link Locking Bolt	M8	8.8	25–30 Nm
Upper Clamp Locking Bolt	M8	10.9	25–30 Nm
Lower Clamp Bolt	M10	10.9	30–35 Nm
Motor Mounting Bolt	M8	10.9	25–30 Nm
Subframe Hanger Bolt	M10	10.9	25–30 Nm
Rear Shock Absorber Mounting Bolt	M10	10.9	25–30 Nm
Rear Sprocket Bolt	M8	10.9	20–25 Nm
Rear Wheel Axle	M20	10.9	30–35 Nm
Brake Lever	M6	8.8	5–7 Nm

10 Cleaning and Storage

10.1 Vehicle Cleaning

Preparation Before Cleaning

Wait until the motor, battery, and controller have fully cooled down.

Ensure all electrical connectors are securely fastened to prevent water intrusion.

Use a pressure washer or water spray to clean the vehicle.

Note!

Do not use gasoline, rust remover, brake cleaner, or similar chemicals on plastic or painted parts — these substances may cause ageing or damage.

After riding in salty or corrosive environments, clean the vehicle as soon as possible to prevent corrosion.

WARNING!

Ensure no cleaning agents or lubricants remain on the brake discs.

Any contamination may lead to brake failure during operation, posing a serious safety risk.

If such substances come into contact with the braking system, clean thoroughly before use.

CAUTION

Use only water and mild cleaning agents, or products specifically recommended by authorised dealers.

Do not use acidic cleaners.

If such agents are used accidentally, clean the affected area immediately to prevent damage.

Dry the motorcycle with a clean towel or sponge after washing.

Always follow the manufacturer's care and cleaning guidelines.

Do not use high-pressure washers or steam cleaners on the motorcycle.

High-pressure water may force moisture into bearings or electrical components, such as connectors, switches, or lighting systems.

This may also damage brake pads, seals, paint, or other parts.

⚠ CAUTION

Salt is highly corrosive.

Follow these cleaning instructions after riding in salty or coastal environments:

Wait until the motor has cooled completely.

Use water and a mild detergent to wash all surfaces.

Clean all metal parts thoroughly and apply anti-corrosion spray to components, including nameplates and nickel-plated surfaces.

Use warm water, gentle detergent, and a soft, clean sponge to remove dirt.

Rinse thoroughly with clean water.

Use a small brush to clean hard-to-reach areas.

After cleaning, apply appropriate protective products to prevent rust.

10.2 Vehicle Storage

For long-term storage, place the vehicle in a cool, dry place, store the sensing wristband safely, and protect with a waterproof cloth cover if necessary.

10.3 Li-ion Battery Storage

Dispose of the battery immediately if the battery case is damaged, do not continue to store it.

Keep the battery away from open flames, cigarettes, or other dangerous environments, and ensure it is placed in a dry and safe location.

Ensure the storage place is equipped with safety protective devices (fire-fighting equipment, fire-fighting facilities).

For detailed information about the battery, please refer to the "Power Components" section.

CAUTION

Always keep the battery with a certain amount of charge. Storing a depleted battery will cause permanent damage to the battery.

WARNING!

Store the vehicle in a well-ventilated place. High humidity air will cause vehicle rust causing component sealing failure.

If you are not familiar with the battery, please contact a professional dealer.

11. Technical Specifications

The following technical specifications describe the standard configuration of the RFN Warrior Pro SX-E15 electric off-road motorcycle. Specifications are subject to change without notice.

Basic Vehicle Parameters

Model	SX-E15	SX-E15 PLUS
Name	RFN Warrior Pro	RFN Warrior Pro
Vehicle Type	Two-wheel Electric Off-road Motorcycle	Two-wheel Electric Off-road Motorcycle
Compliance	CE	CE
Rated Voltage	74V	74V
Dimensions (L×W×H)	1980*820*1180mm (78 × 32.3 × 46.5 in)	2030*820*1230mm (80 × 32.3 × 48.4 in)
Wheelbase	1340mm (52.8 in)	1340mm (52.8 in)
Ground clearance	293mm (11.5 in)	333mm (13.1 in)
Seat Height	880mm (34.6 in)	930mm (36.6 in)
Ground Clearance	293mm (11.5 in)	333mm (13.1 in)
Steering Angle	45°	45°
Trail	90mm(3.5in)	90mm(3.5in)

Li-ion Battery Pack and Range

Capacity	40 Ah / 2960 Wh	40 Ah / 2960 Wh
Discharge Rate	8C	8C
Rated Discharge Current	150A	150A
Peak Discharge Current	250A	250A
Certification	CE 1542, EN50604	CE 1542, EN50604
Control System	CANBUS	CANBUS
Range	110 km at 60 km/h	110 km at 60 km/h
Battery Detachable	Yes, removable for charging	Yes, removable for charging
Battery Lifecycle	300 cycles	300 cycles
Charging Time	4.5 hours	4.5 hours

Motor and Performance

Motor Type	Permanent Magnet Synchronous Motor	Permanent Magnet Synchronous Motor
------------	------------------------------------	------------------------------------

Rated Power	8 kW	8 kW
Maximum (Peak) Power	15 kW	15 kW
Maximum Speed	90 km/h	100 km/h
Maximum Wheel Torque	130 N·m (106.95 ft·lbf)	130 N·m (106.95 ft·lbf)
Climbing Angle @10 km/h	30°	30°

Transmission System

Drive System	Chain Drive
Drive Ratio	11:48
Chain Type	520

Suspension System

Front Suspension	Length: 850mm (33.5 in), Travel: 240 mm (9.4 in)	Length: 880mm (34.6 in), Travel: 240 mm (9.4 in)
Rear Suspension	Length: 330 mm (13 in), Travel: 83 mm (3.3 in)	Length: 330 mm (13 in), Travel: 83 mm (3.3 in)

Braking System

Front Brake	240 mm (9.4 in) Disc Brake
Rear Brake	220 mm (8.7 in) Disc Brake

Tires and Weight

Front Tire Size	70/100-19	80/100-21
Rear Tire Size	90/100-16	100/90-18
Front Rim	WM1.6-19	WM1.6-21
Rear Rim	WM1.85-16	WM1.85-18
Curb Weight	86 kg (189.6 lb)	90 kg (198.4 lb)
Maximum Load	120 kg (264.5 lb)	120 kg (264.5 lb)

Handlebar and Frame

Handlebar Diameter	Φ 28.5–Φ 22
Frame	High-Strength Welded Aluminum Frame
Rear Swing Arm	Integrated Forged & Welded Swingarm
Seat	PU Foam Seat
Color	Customizable

Recommended Tire Pressure

Front Tire	1 Bar (14.7 psi)
Rear Tire	1 Bar (14.7 psi)

Note!

The specifications listed above are standard for the SX-E15. The actual vehicle may differ slightly due to continuous product improvement. If you have any questions about the specifications, please consult your authorized dealer.

 WARNING!

Maximum rider weight must not exceed 120 kg (264.5 lb). Exceeding this limit may affect vehicle performance and safety.

12. Warranty and Guarantee

Before operating the motorcycle, carefully read the user manual to become familiar with its operation.

You must follow all usage, care, and maintenance instructions provided in this manual to retain warranty coverage and eligibility for claims.

Proper adherence to these guidelines will significantly increase the service life of your motorcycle.

From the date of first delivery to the end customer, a 12-month limited warranty (or the applicable legal warranty period) is granted on major vehicle components, covering defects in materials or workmanship (see “After-Sales Service and Warranty Scope” table for details).

All warranty repairs must be carried out by an authorised service facility.

No warranty claims may be made for damages caused by improper use, operation, or disregard of the instructions in this manual.

Warranty claims are valid only when any damage is reported directly to the seller or an authorised dealer without delay.

Under warranty, the customer is entitled solely to the correction of the defect.

No compensation will be provided for direct or indirect damages.

Neglected vehicles are excluded from warranty and guarantee claims.

To maintain the condition of the bodywork and trim components:

Clean regularly to remove dirt and grime.

Never use high-pressure washers, jet sprays, sharp tools, corrosive, or abrasive cleaners, as these can permanently damage surfaces and paintwork, and may accelerate rust.

Use mild cleaning and care products as recommended by your authorised dealer.

For refined metal surfaces (e.g. chrome, anodised, or polished aluminium), apply suitable protective products to prevent oxidation.

Always apply proper corrosion protection to the frame and metal components to avoid rusting.

Vehicles that are parked outdoors for extended periods must be covered with a waterproof protective cover to prevent weathering of painted parts, and to protect seats and other plastic components from cracking.

Note!

If the vehicle is used in competitive racing events, all warranties and guarantees are void.

13. After-Sales Service and Warranty Coverage Table

13.1 Start Date & General Provisions

- Warranty start date: calculated from the vehicle production date.
- When both calendar time and mileage are specified, whichever comes first applies. If only one is specified, that condition applies.
- The warranty covers defects in materials or workmanship only; damage due to misuse, impact/water ingress/modification, overloading, lack of maintenance, or use of non-approved parts/fluids is excluded.

13.2 Coverage Table (materials/workmanship defects only)

System/Component	Coverage Period	Scope of Coverage	Notes/Exclusions
Battery pack (incl. BMS)	24 months	Charging/discharging anomalies; BMS/cell manufacturing defects	Excludes deep discharge/improper storage, water/high- pressure ingress, mechanical shock, unauthorized opening, or use of non- OEM charger.
Electric motor (PMSM)	24 months	Internal electrical/mechanical manufacturing defects	Excludes water/foreign- object ingress, mis- wiring, tuning/flashing, over- temperature use, or improper cleaning.
Motor controller / inverter	24 months	Functional failure or abnormal derating due to manufacturing defects	Excludes reverse polarity/shorts, non- authorized tuning/flashing, or non- approved accessories.
Charger (on- board / external)	24 months	Charging failure or protection malfunction due to manufacturing defects	Excludes non- compliant power sources, connector modification, liquid ingress/corrosion, or misuse.
Front/rear hubs (excl. tires)	10,000 km	Casting/machining/assembly defects	Excludes impact deformation, spoke loosening from misuse, rim dents.
Front fork assembly	6 months or 3,000 km (whichever comes first)	Structural/manufacturing defects of the fork assembly	Seals/dust wipers are wear items; excludes leaks due to contamination, scratches, modifications, or heavy jump impacts.
Rear shock absorber	6 months or 3,000 km (whichever comes first)	Structural/manufacturing defects of the shock body	Seals are wear items; excludes leaks due to modifications, severe impacts, or contamination.
Instrument cluster	12 months	Display/button/PCB manufacturing defects	Excludes impact cracks, liquid ingress/corrosion, or non- authorized disassembly.
Main wiring harness	12 months	Open circuits/poor connections caused by manufacturing defects	Excludes abrasion wear, bent pins, water/corrosion, or modified splices.
Seat assembly	12 months	Foam/cover manufacturing defects	Excludes normal wear, scratches, UV aging, chemical damage.
Brake disc (rotor)	Lifetime replacement for manufacturing defects	Material/manufacturing defects only	Excludes normal wear, heat fade/warpage from misuse/incorrect installation.
Mode/gear buttons & switches	12 months	Internal switch/circuit manufacturing defects	Excludes water ingress, impact, unauthorized disassembly, or wiring modifications.
Emergency cut- off switch	12 months	Contact/reset mechanism manufacturing defects	Excludes water ingress, impact, unauthorized disassembly, or wiring modifications.
Front brake assembly (excl.	12 months	Master cylinder/caliper casting or seal defects	Pads are consumables; excludes leaks caused by

pads)			misuse/modification/contamination.
Rear brake assembly (excl. pads)	12 months	Same as front	Same as front.
Rear/front sprocket	5,000 km	Material/machining defects	Excludes normal wear or abnormal wear due to improper chain tension.
Drive chain	1,500 km	Manufacturing defects (early breakage/rivet defects, etc.)	Consumable; excludes elongation wear due to lack of lubrication, improper tension, or dirt ingress.
Electronic throttle (Hall-sensor throttle)	12 months	Manufacturing defects of internal Hall sensor/return spring/circuit causing abnormal output, dead zone, or return failure.	Excludes impact damage, liquid ingress/corrosion, wiring modifications, unauthorized disassembly, or contamination causing sticking.

13.3 Exclusions / Warranty Void

- Any competition or racing use (official or not) is excluded.
- Misuse or operation contrary to this manual (overloading, deep- water immersion, corrosive/high- pressure washing, prolonged outdoor storage without protection, etc.) is excluded.
- Non- authorized disassembly, modification, ECU re- flash, or use of non- OEM/non- approved parts/fluids is excluded.
- Abnormal wear or failures due to missed service, missing records, or usage far beyond intended conditions are excluded.
- No compensation for direct/indirect or consequential losses; the sole remedy is defect correction (repair or replacement).
- Wear parts excluded unless proven manufacturing defect at delivery: tires, brake pads/discs, chain/sprockets, bearings, seals, bulbs, grips, seat cover, fastener loosening, normal fading/scratches, etc.

13.4 Customer Rights & Service Modality

- During the warranty period the customer is entitled to defect correction (repair or replacement with equivalent parts). Replacements do not extend the original term.
- Service is available only through RFN Authorized Service Centers.

13.5 Claim Procedure

- 1) Stop using the vehicle and contact the seller or an authorized service center without delay.
- 2) Provide VIN, proof of purchase, service records, fault description, and photos/videos.
- 3) Authorized diagnosis → factory review → approved warranty repair/replacement.

4) If deemed non-warranty, transport/disassembly/diagnosis costs are borne by the customer.

13.6 Transfer

- Warranty is transferable with the vehicle provided full maintenance/repair records are supplied and further service continues within the authorized network.

14. Maintenance Guide

*The inspection frequency must be observed, otherwise the warranty will be invalid.		The 1st 1000KM	Every 1000 KM	Every 3000KM	Every year
Component	Activity				
display , switch	Check	Check			
electric system	Check	Check			Check
battery	Check	Check			Check
front-wheel bearing	Check and replace	Check		Check	
rim	Check and replace	Check	Check		
brake system	Check and replace	Check		replace	
braking line	Check			Check	
brake disc	Check, clean and replace	Check		clean	
braking flu id	Check and replace	Check		Check	
brake pads	Check and replace	Check	replace	replace	
chain, rear sprocket	Check, clean and replace	Check and clean		replace	
front shock absorber	Check and clean	Check		Check and clean	
rear shock absorber	Check and clean	Check		Check and clean	
steering bearing	Check	Check		Check	
side stand	Check, clean and lubricate	Check, clean and lubricate	Check, clean and lubricate		
tight of all visible screws and nuts	Check	Check		Check	
Light	Check and clean	Check and clean	Check and clean	Check and clean	Check and clean

Maintenance should be performed based on whichever comes first: the specified time interval or mileage.

CAUTION

Inspect the motorcycle regularly for signs of rust.

The owner is responsible for performing routine anti-corrosion maintenance.

WARNING!


Appropriate maintenance must be carried out in accordance with the prescribed schedule.

Warranty coverage is valid only if the vehicle has been properly maintained according to this plan.

14.1 Electrical System Diagram

Note!

Dashed lines in the schematic represent optional accessories that may be installed additionally.



14.2 Electric Motorcycle Troubleshooting

All RFN electric motorcycles undergo strict quality inspection before delivery.

However, despite thorough checks, technical issues may still occur over time.

The following information provides guidance to help you identify possible problems and carry out minor maintenance where applicable.

If you are unable to resolve the issue, please take the vehicle to an authorised dealer.

If no dealer is available in your region, contact the manufacturer's after-sales service team.

Important Safety Notice – High Voltage Handling

RFN motorcycles contain high-voltage components.

Please observe the following safety precautions at all times:

High-voltage components can cause burns, electric shock, or serious injury.

Always follow the warning labels affixed to components.

Do not touch, remove, or attempt to replace any high-voltage parts, cables, or connectors.

In the event of an accident, do not touch any orange high-voltage cables or connected components.

If the motorcycle catches fire, and only if it is safe to do so, use a Class D fire extinguisher.

After extinguishing the flame, cool the area thoroughly with large volumes of water or a water-based extinguisher.

WARNING!

Always obey the warning labels attached to the motorcycle.

RFN Warrior Pro operates on a 74V high-voltage system.

Beware of high voltage and also high temperatures in the drive system immediately after operation — do not touch.

EXTREME DANGER!

High-voltage cables are marked in orange for easy identification.

The high-voltage system must never be serviced by users.

Removing or replacing any high-voltage components, cables, or connectors may result in severe burns, electric shock, or even death.

Battery Safety Lockout Behavior

To protect the battery pack, the Battery Management System (BMS) may activate one or both of the following protective lockouts if a critical internal fault is detected:

Operation lockout:

If the battery is fully discharged or if a critical fault is detected, vehicle operation will be disabled until the issue is resolved.

Charging lockout:

If a serious fault is detected, the system will prevent charging even when the battery is connected to a charger and AC power is supplied.

System Fault Alerts

If the vehicle detects a fault, the system warning indicator area A of the instrument will light up and the corresponding fault code will be displayed in area B.



Note!

In fault conditions, the vehicle may be locked in P mode, or limited to restricted riding modes.

Speed, units, and mode indicators may also disappear from the instrument cluster.

A table listing common fault codes, possible causes, and suggested solutions is typically provided on the next page for reference.

14.3 Fault Code Table – Error List and Recommended Actions

Error Code	Fault Description	Troubleshooting Solution
01	Controller Bus Overvoltage	Do not push the vehicle by force; disable regenerative braking.
02	Controller Bus Undervoltage	Charge the battery pack.
03	Controller Phase Current Overcurrent	Check for motor blockage, shut down the vehicle, or use the lowest power mode.
04	Controller Overload	Vehicle enters limited power output mode.
05	Controller U Phase Loss	Shut down the vehicle and check motor phase cable connections.
06	Controller V Phase Loss	Shut down the vehicle and check motor phase cable connections.
07	Controller W Phase Loss	Shut down the vehicle and check motor phase cable connections.
16	Motor Stalled	Check if the motor is blocked and disable power signal.
17	Motor Overtemperature	Stop and wait for the motor to cool down.
18	Motor Overspeed	Stop the vehicle and do not push it manually.
19	Controller Overtemperature	Stop and wait for the controller to cool down.
23	Throttle Fault – Not Reset or Disconnected	Release throttle and check for short/open circuit or physical damage.
25	Gear Switch Fault	Check if the gear switch is stuck or replace the switch.
57	Battery Cell Overvoltage	Shut down and disconnect the battery; contact the manufacturer or dealer.
58	Battery Cell Undervoltage (Low SOC)	Charge the battery.
60	Cell Voltage Imbalance	Shut down and disconnect the battery; contact the manufacturer or dealer.
65	Battery Discharge Overcurrent	Stop and contact the manufacturer or dealer.
69	Battery Hardware Overcurrent Protection	Stop and contact the manufacturer or dealer for BMS inspection.
73	Battery Overtemperature	Stop and wait for the battery to cool down.
74	Battery Undertemperature	Stop and do not charge; wait until temperature rises.
75	BMS Overtemperature	Stop and do not charge; wait for temperature to return to normal.
76	BMS Undertemperature	Stop and wait until temperature rises.
77	Battery MOSFET Overtemperature Protection	Stop and wait until battery temperature normalizes.
83	Battery Overdischarge Protection	Shut down the vehicle and charge the battery.
84	Single Cell Overdischarge Protection	Charge the battery or contact the manufacturer/dealer.
85	Battery High Humidity Protection	Shut down and store in a dry environment or contact the manufacturer/dealer.
87	Battery Immersion Protection	Contact the manufacturer or dealer for battery replacement.
105	Charger Input Undervoltage Protection	Replace the charger or contact the manufacturer/dealer for repair.
106	Charger Output Overvoltage Protection	Replace the charger or contact the manufacturer/dealer for inspection.
109	Charger Overtemperature Protection	Disconnect the charger and stop charging or replace the charger.

14.4 General Troubleshooting Table

Symptom	Possible Cause	Recommended Action
Vehicle has no power after startup	Battery plug not properly connected	Check battery plug
	Battery in sleep mode due to low charge	Recharge battery
	Battery protection due to low/high temperature	Wait until battery returns to normal temperature
	Battery malfunction	Contact authorised service centre
	DC output cable disconnected	Check for pin damage or loose contact
	Main cable diode damaged	Inspect and replace harness
	Display/start switch connector loose	Check and reinsert plug firmly
	Faulty display or switch	Inspect or replace instrument/switch
Power on, but throttle not working	Kickstand switch protection active	Check or retract side stand
	Emergency cut-off switch active	Reset switch or check wiring
	Throttle not returned on startup	Return throttle to rest or replace
	Battery low-voltage protection	Recharge battery
	Motor/controller over-temperature protection	Wait to cool
	Throttle grip malfunction	Replace throttle
	Controller plug loose	Reconnect controller signal plug
	Motor encoder plug loose	Reconnect encoder plug
Battery info not shown on display	Controller or encoder failure	Replace at authorised service centre
	Communication fault or broken wire	Repair or replace battery at service centre
Charger not working	Display damaged	Replace at authorised service centre
	Battery too cold/hot	Wait for temperature normalization
	Loose charger plug	Reconnect charger
	Charger malfunction	Replace charger
	Battery malfunction	Replace or service battery
Power mode invalid / power reduced	Low battery charge	Recharge battery
	Battery temperature too low/high	Wait until temperature is within range
	Motor/controller over-temperature	Wait until cooled
	Motor internal wear/failure	Replace motor
	Power mode switch failure	Replace switch

Reminder:

For other fault codes, connect to the vehicle's mobile app or use diagnostic equipment at an authorised dealer.

Severe faults may require dealer-only tools with elevated permissions.

Always refer to the latest service documents from your dealer or manufacturer.

15. Technical Specifications

At the time of vehicle handover, the following information must be completed and retained as part of the official service record.

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

Current Mileage: _____

Date: _____

Dealer Stamp & Signature:

(Authorised Dealer/Technician)

This record confirms the official delivery of the vehicle to the end customer and establishes the baseline for future warranty and maintenance tracking.



**RFN Warrior Pro
SX-E15 / E15 Plus**

©2025 RFN. All rights reserved.

Complies with:

- EU: EMC Directive 2014/30/EU
- US: CPSC 16 CFR Part 1512
- Battery disposal: Follow local WEEE regulations (♻️ symbol)